


Using the Portable Power Bank



Step 1: Charging the Power Bank

- Plug the standard end of your USB cable in to your power source (AC wall Adapter or powered computer USB port) and the Micro end of the cable into the Power IN port on the device.
- The power button and charge indicator lights will light up briefly, and the charge indicator lights will begin lighting in sequence, indicating that the device is charging.
- Once the indicator lights are all lit, and stay lit, your device is fully charged.

Step 2: Using the Power Bank to charge your tablet

- When your tablet is running low on battery, press the power button on the Portable Power Bank once briefly to turn it on.
- Connect the standard end of your USB cable to the Power OUT port on the device, and the Micro USB end to your Tablet.
- Once your Tablet is charged, disconnect the USB cable from the tablet, and then the Portable Power bank, and power it off by tapping the power button once briefly.

OTHER NOTES:

- Never attempt to charge the power bank when charging your tablet. This will damage the power bank and tablet, and void your warranty.
- This device comes with a built in LED flashlight. To activate this, press and hold the power button for 3 seconds. Press and hold the power button for 3 seconds again to power the flashlight off.
- The Portable Power Bank stores up to 6000 mAh of energy. This will charge your infinity tablet 1.5 times.
- You can use your Portable Power Bank to charge other battery powered devices, including many Smartphones and MP3 players.
- If you have any questions regarding your Portable Power Bank, please contact our technicians by phone at 580.272.0035 or by email at mssupport@machspeed.com.